



ASSEMBLY INSTRUCTION FOR 32366

1. CONNECT ELECTRICAL WIRES AT JUNCTION BOX AND SECURE BRACKET (A).
2. USE LOCK UP NUT (C) TO SECURE FLUSH PAN (B).
3. INSTALL LIGHT BULBS NOT PROVIDED.
4. SECURE GLASS (E) WITH NIPPLE (D), CAP (F), NUT (G) AND FINIAL (H) ACCORDINGLY.

